T - 3991 _ PRO-CAD & PRO-FAD



General description

The access doors for rectangular ducting (PRO-FAD) and for round ducting (PRO-CAD) consist of two panels connected between themselves with two screws, springs and knobs. The inner panel will be slided inside the duct, and the outside panel will then be compressed by tightening both knobs.

A self-adhesive rubber protective gasket is supplied with each door in order to protect the sharp edges of the duct opening and prevent injuries. It allows a better airtightness (class C) of the access doors.

Access doors allow easy admittance to the ventilation ducting for the purpose of inspection and cleaning.

Blue knobs are delivered as standard. Red knobs available on request.




Technical specification

PANELS	Material	Galvanized steel Z275		
SEALING GASKET	Туре	High quality EPDM gasket		
	Dimension	6 mm x 15 mm		
	Density	+/- 33 Kg / m³		
COMPONENTS Screws		2 screws: M8x40 or M10x40 crimped on internal panel		
COMPRESSION SYSTEM Springs Knobs		2 compressions springs		
		2 plastic knobs with metal insert M8 or M10		

Self-adhesive template comes with each door, for accurate cut-out


PROTECT			
Material	EPDM		
Shore	20 / 25 Sh A		
Color	Black		
Adhesive	Rubber		
Temperature of use	- 30 °C / +100 °C		
Tightness	Reaches Class C		





Sizes

Door type	Nominal sizes	Actual Dimensions (mm) The format is oblong, and the radius of the 4 angles is equivalent to the small size divided by 2.				
mm (mm	(mm)	Α	В	С	D	
18	180 x 80	170	72	197	101	
20	200 x 100	200	100	219	117	
25	250 x 150	250	150	274	186	
30	300 x 200	300	200	329	228	
42	400 x 200	380	180	412	212	
40	400 x 300	380	280	403	303	
50	500 x 400	500	400	532	432	
60	600 x 450	600	450	627	480	




A & B = opening dimensions C & D = external dimensions

T - 3991 _ PRO-CAD & PRO-FAD




CAD selection chart for round ducting

Door size Duct dia.	180x80 mm	200x100 mm	250x150 mm	300x200 mm	400x300 mm	500x400 mm	600x450 mm	Recommended door curving diameter (mm)
100 mm	Standard	-	+	-	-	-	-	100
125 mm	Standard	-	+	-	-	-	-	
140 mm	+	Standard	+	-	-	-	-	125
150 mm	+	+	+	1	-	-	-	
160 mm	Standard	+	Standard	1	-	-	-	100
180 mm	+	Standard	+	-	-	-	-	160
200 mm	Standard	Standard	Standard	-	-	-	-	200
224 mm	+	+	+	-	-	-	-	200
250 mm	+	Standard	Standard	-	-	-	-	
280 mm	+	+	+	-	-	-	-	250
300 mm	+	+	+	-	-	-	-	
315 mm	-	Standard	Standard	Standard	-	-	-	315
355 mm	-	-	Standard	Standard	-	-	-	355
400 mm	-	-	Standard	Standard	Standard	-	-	400
450 mm	-	-	Standard	Standard	Standard	-	-	450
500 mm	-	-	Standard	Standard	Standard	-	-	500
550 mm	-	-	-	+	+	-	-	
560 mm	-	-	-	+	Standard	-	-	560
600 mm	-	-	-	+	+	-	-	
630 mm	-	-	-	+	Standard	Standard	-	630
700 mm	-	-	-	-	+	+	-	710
710 mm	-	-	-	-	Standard	Standard	Standard	710
800 mm	-	-	-	-	Standard	Standard	Standard	800
850 mm	-	-	-	-	+	+	+	
900 mm	-	-	-	-	Standard	Standard	Standard	000
1000 mm	-	-	-	-	+	Standard	Standard	900
1120 mm	-	-	-	-	+	Standard	Standard	1120
1250 mm	-	-	-	-	+	Standard	Standard	1250
1400 mm	-	-	-	-	-	-	Standard	
1500 mm	-	-	-	-	-	-	Standard	
1600 mm	-	-	-	-	-	-	Standard	
1800 mm	-		-	-	-	-	Standard	



- : Not available



T - 3991 _ PRO-CAD & PRO-FAD





Recommendations (based on EN 12097)

Access door needs to be fitted:


- before and after every fitting (dampers, fire dampers, filters, duct fans, duct heaters,...)
- after more than one change of direction of more than 45° as from the access door
- · after more than one change of airflow as from the access door
- · at least every 7,5 m

ROUND DU	ICTING (CAD)	RECTANGULAR DUCTING (FAD)		
Nominal duct diameter (mm)	Minimal size of access door (mm) A x B	Width of duct where access door is fitted (mm) S	Minimal size of access door (mm) A x B	
100 ≤ D < 200	180 x 80	S ≤ 200	180 x 80	
200 ≤ D ≤ 315	250 x 150	200 < S ≤ 400	300 x 200	
315 < D ≤ 500	300 x 200	400 < S ≤ 500	400 x 300	
500 < D	400 x 300	500 < S	500 x 400	







Application



1. Stick self-adhesive template on to duct (a template is provided with each door)




2. Using Turbo Shears or similar cut around template taking care not to exceed the size of the template (the door will function correctly when cut to template size +0 mm -3 mm).



3. Set the protect rubber around the edges of the opening. And ensure it is evenly installed.



4. Install door by unscrewing the hand knobs until thread is level with top of bolt. Using both hands place the door in the hole at an angle.



5. Turn straight and pull out slighlty to align. Then tighten knobs.

TECHNICAL DATA SHEET

(4/4)

T - 3991 _ PRO-CAD & PRO-FAD







DE 633X206 VE 305/3/FR Page 4/5







